



Setting the Standard for Wear!

R & H WELD-ON OPENERS and PLOW PARTS

R & H Machine offers a wide variety of weld-on openers, many of which are pre-welded onto either 3/8" mild-steel backing or 3/16" T-1 steel backing for ease of installation. The cap is wider than the backing to reduce wear on the shank.

Important Instructions for Welding!

1. All R & H Chrome Alloy weld-on parts must be heated to a **bright, cherry red** before welding.
2. Base parts will need to be trimmed first to fit the inserted part.
3. Use either stick or wire feed with mild-steel rod or wire such as 6011.
4. Welding must be done with the casting **red**, and the base part warm to prevent cracking.
5. Room-cool out of draft.

RH 445 ASSEMBLY

FLAT OPENER POINT with SHANK

Height: 10"
 Width: 1-1/2"
 Thickness: 3/8"
 Hole spacing: 2" to 2-3/4"
 Holes: 1/2" x 1-1/4" slotted



Assembly description:

One RH 445B attached to mild-steel shank with 4-1/2" piece of RH 16 installed as a shin guard.

R & H parts outshine the competition!!!

RH PRE-WELDED OPENERS with BACKING

RH 442 B WELD-ON SMALL SPIKE POINT with BACKING

Length: 4"
 Width: 2"
 Notch:
 Length: 1-3/8"
 Width: 3/4"



Thickness: 7/8" (including 3/8" steel backing)

RH 443 B WELD-ON LARGE SPIKE POINT with BACKING

Length: 5"
 Width: 2-1/2"
 Notch:
 Length: 2"
 Width: 3/4"



Thickness: 7/8" (including 3/8" steel backing)

RH 444 B WELD-ON OPENER with BACKING

Length: 4-3/8"
 Width: 3-1/4"
 Notch:
 Length: 1/1/2"
 Width: 3/4"



Thickness: 3/8" (including 3/16" T-1 steel backing)

RH 445 B WELD-ON OPENER with BACKING

Length: 4-3/8"
 Width: 5-1/8"
 Notch:
 Length: 1-7/8"
 Width: 1/2"



Thickness: 7/16" (including 3/16" T-1 steel backing)

RH WELD-ON OPENERS

RH 440 WELD-ON OPENER

Length: 5"
Height: 1"
Thickness: 3/8"



RH 448 WELD-ON POINTED OPENER

Length: 3-1/4"
Height: 4"
Thickness: 3/4"



RH 441 1" WELD-ON OPENER

Sides: 3" x 3-5/8" x 4-3/4"
Thickness: 1"



RH 441-.75 3/4" WELD-ON OPENER

Sides: 3" x 3" x 4-1/4"
Thickness: 3/4"



RH 441NRL 5/8" ROUNDED WELD-ON OPENER

Sides: 3-1/2" x 4-3/4" x 6-7/8"
Thickness:
Body: 1/2"
Nose: 5/8"



RH 441NR 5/8" ROUNDED WELD-ON OPENER

Sides: 3" x 3-1/2" x 4-5/8"
Thickness:
Body: 1/2"
Nose: 5/8"



RH 447 RENOVATOR POINT

To fit: Hay King renovator

Length: 8"
Height: 6-1/2"



RH 446 WELD-ON FIN OPENER

Length: 5-1/2"
Width: 4"
Thickness: 3/4"



RH 346 OPENER INSERT / PLANTER

Length: 3-1/4"
Height: 5-1/4"
Thickness: 2"



RH 449 WELD-ON OPENER

Length: 5-1/4"
Height: 3-3/8"
Thickness: 3/4"



RH 346 L LONG OPENER INSERT / PLANTER

Length: 3-3/8"
Height: 7-3/8"
Thickness: 2"



RH PLOW PARTS

*** MOLDBOARDS ***

RH 416 MOLDBOARD COVER

To fit: Long switch plow



Length: 9-7/8"
Width: 11-3/4"
Thickness: 1/2"
Bolt holes: 1/2"

RH 417 MOLDBOARD COVER

To fit: Long switch plow



Length: 9-7/8"
Width: 11-3/4"
Thickness: 1/2"
Bolt holes: 1/2"

NOTE: use 2-RH 416's and 2-RH 417's to make complete moldboard cover.

*** WELD-ON PLOW POINTS ***

RH 415 LEFT or RIGHT EXTENDED PLOW POINT

To fit: Wilcox



LEFT

Length: 8-1/2"
Width: 3"
Thickness: 7/8"

RIGHT



RH 418 PLOW POINT

Length: 10-1/8"
Height: 5"
Thickness: 5/8"



RH 419 LEFT or RIGHT PLOW CAP

Length: 6"
Height: 5-1/2"
Thickness: 1/2"



RH LAND SLIDES

RH 421 LEFT or RIGHT LAND SLIDE

To fit: JD plow (replaces JD part # 16495 and 6)



LEFT

Length: 7"
Width: 4"
Thickness: 1/2"



RIGHT

Hole spacing: 4-5/8"

Bolt holes: 7/16" hex

RH 425 LEFT or RIGHT LAND SLIDE

To fit: CaseIH plow (replaces Case part #1980947C2)



LEFT

Length: 6"
Width: 4-1/2"
Thickness: 1/2"



RIGHT

Hole spacing: 3-1/16"

Bolt holes: 7/16" hex

RH 420 LAND SLIDE

To fit: JD plow (replaces JD part #57046)

Length: 6-1/2"
Width: 4"
Thickness: 1/2"



Hole spacing: 3-9/16"
Bolt holes: 7/16"